



Ex:
Isf = 400A
Isn = 100A
Slop = I²T
Long I = 0,3 x
Long Delay = 16
Short I = 2 x
Short T = 0,2s
Inst = 4 x
Ground I = 0,2 x
Ground Delay = 0,1s